

audison

| bit

CONTROL FIRMWARE
UPGRADE

bit Play HD

v.2.0.0.2




ideato,
progettato,
costruito
in Italia


All FIRMWARE updates must be performed in strict accordance with the following procedures.

The FIRMWARE update must be performed with the utmost care, following the precautions displayed on the monitor, to prevent damage to the product.


1. Turn off the bit Play HD.
2. Copy the file "bitPlayHD_v2.0.0.2.hex" to the PC Desktop.
3. Connect the PC to bit Play HD "PC" plug, with USB cable.
4. Power and turn On the bit Play HD
5. Launch the "Audison bit Play HD control firmware update" loaded file.




6. Select the entry "SEARCH"; the software will ask you to select the file "bitPlayHD_v2.0.0.2.hex", that you have previously saved in your PC Desktop.



7. Select the entry "UPDATE" the software will offer the following warnings:
 - close all running applications;
 - disable standby and energy saving features;
 - disable anti-virus and anti-spyware systems.
 Select "Yes" to continue.



8. Once the update has been successfully completed the window you can see on your right will appear. Select "OK" to continue.



9. Exit the program, by clicking on X; then turn the bit Play HD off.
10. Disconnect the PC to bit Play HD "PC" plug, with USB cable.